
# RX72F & RX72F-PS

#### **Flush Mount Lift Rack**

# **HUNTER**Engineering Company

#### **SPECIFICATIONS**



RX72F-PS Shown (jacks optional)

#### Power Requirements (for available models)

215E 200/208/230 VAC, 1 phase, 50 or 60 HZ, 26 Amp draw

435E 208/230/400/460 VAC, 3 phase, 50 HZ, 18 Amp (208/230) / 9 Amp (400/460) draw

#### Site Specifications (Refer to 7065-TE for full site requirements)

Air Supply Requirements

6.2-10.3 bar (90-150 PSI)

Jacks require 8.6 bar (125 PSI) @ full capacity

Minimum Concrete Spec. 76 mm (3 in.) thick, 20,700 kPA (3000 PSI) rating


Maximum Floor Slope 51 mm (2 in.) over 3200 mm (126 in.)


Maximum Floor Slope	51 mm (2 in.) over 3200 mm (126 in.)		
Product Specifications			
Max. Vehicle Weight	7200 kg (16,000 lbs.)		
Max. Wheelbase			
General Service	4750 mm (187 in.)		
Two-Wheel Alignment	4623 mm (182 in.)		
Four-Wheel Alignment	4013 mm (158 in.)		
Alignment Height	All lock positions		
Min. Four-Wheel Alignment	2235 mm (88 in.)		
Lifting Speed	1-speed, 60 seconds		
Lowering Speed	2-speed, 25 seconds		

#### **MODEL FEATURES / DIMENSIONS**

Features	F	F-PS
2-Speed Lifting and Lowering		Ø
Fully Integrated Alignment		Ø
POWER    SLIDE		Ø
INFLATION STATION		
9000-lb Swing Air Jacks	Available	e Option

Dimension		
Outside Width (W1)	2350 mm 92.5 in.	
Inside Width (W2)	1016 mm <sup>40</sup> in.	
Length (L)	<b>5877 mm</b> 231.375 in.	
Deck Length (DL)	<b>5512 mm</b> 217 in.	
Runway Width (R)	660 mm 26 in.	
Raised Height (H1)	1829 mm 72 in.	
Stack Height (H2)	375 to 387 mm 14.75 to 15.25 in.	






Continued on Page 2

## RX72F & RX72F-PS

Flush Mount Lift Rack



### SPECIFICATIONS (Refer to 7065-TE for full substructure construction requirements)



<sup>\*</sup>Non-standard positioning of control console is limited to a maximum space between console and rack of 1829 mm (72 in.) at the approach ramp end and 5182 mm (204 in.) at the turnplate end. Additional threshold and perhaps hydraulic hoses will be required (refer to Installation Instruction for details).